

# Manual Led Eyelashes

## Contains:

Battery

2 Led Eyelashes (wired)

Controller

Barrette

## How it works

1. Pull the plastic cover out of the controller, this way the battery will make contact to the circuit board. When replacing the battery, it must be faced with the convex surface towards the circuit board.
2. Slide the plugs into the controller.
3. Push the button for seconds straight.
4. The Eyelashes are ready to shine!

## Usage of the Eyelashes

You can apply the Eyelashes with glue (not included). It is recommended to use False-Eyelashes glue, due to the fact that it won't cause any irritation. Strong glue is not recommended!

After use, we advise to clean the Led Eyelashes with a dry napkin. After cleaning the Led Eyelashes can be used again.

## Light movements

The Led Eyelashes are showing random light patterns, this is activated by the movement of your head.

The following patterns are available:

“Liquid Pour”



“Knight Riding”



“Hyper Burst”



“Twilight Sparkle”



“Endless Winks”

